How to seal skylights, vents, chimneys & other roof projections

USING CLEAR LEAK STOPPER™ TO CREATE AN INVISIBLE WATERPROOF SEAL

1. Apply **Clear Leak Stopper** as you would a latex sealant. Do not apply if rain or temperatures colder than 40 F are expected within 24 hours.
2. Prepare the surface by removing any dirt, leaves, dust, grime, sap, oil, mold/mildew, or other contaminants.
3. Cut the tube at a 45 angle to create an applicator tip. Cut tip to create a 1/8" to 3/8" bead. Remember sealants shrink when drying due to evaporation.
4. With a caulk gun apply a continuous, even bead. Hold the gun at a 45 angle and pull toward you, pushing caulk into the gap.
5. Smooth or “tool” the bead to a concave shape using a caulk finishing tool or wet fingertip. Be careful only to shape the bead—not remove it!

SEALING AND WATERPROOFING OTHER ROOF PROJECTIONS

1. Apply **Black Jack** roof cement at base of projection. Spread the cement around the repair.
2. Embed **Universal Patching Fabric** into the cement directly over repair area to strengthen the repair.

3. Apply additional **BlackJack®** brand roof cement over fabric to completely seal the repair.

PROJECT HOW-TO'S™ COPYRIGHT © 2005 - 2012, GARDNER-GIBSON, INC.